

Optimus 3D

Maintenance Service Manual

Contents

1.Maintenance Considerations

① · Replacement of Backrest Pad

2.Error Code and Error Analysis

② · Replacement of Back Cover

3.Electrical Schematic Diagram

③ · Replacement of Side Plate

4.Explosive View

④ · Replacement of Shoulder

5.Tools List

⑤ · Replacement of Leg Rest

6.Replacement of Accessories →

⑥ · Replacement of Air Pump

⑦ · Replacement of Switching Power Supply

⑧ · Replacement of the Main PCB box of
Quadruple Air Valve

⑨ · Replacement of the main PCB box of
Duplex Air Valve

⑩ · Replacement of Remote Control

⑪ · Replacement of Main PCBA and Fuse

⑫ · Replacement of the Rolling Mechanism

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

Read all instructions before using (this appliance).

DANGER To reduce the risk of electric shock:

- Always unplug this appliance from the electrical outlet immediately after using and before cleaning.
- Never use pins or other metallic fasteners with this appliance.
- Carefully examine the covering before each use. Discard the appliance if the covering shows any sign of deterioration, such as checking, blistering, or cracking.

WARNING To reduce the risks of burns, fire, electric shock or injury to persons:

- An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.
- Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.

2. Error Code and Error Analysis




Optimus 3D Error Code Explanation

Error numbe	Error description	Possible cause	Exclusion method	Remarks
1	The hand controller button was pressed for more than 45s without letting go	Button stuck	1.Check the status of each button carefully; 2. Replace the hand controlle.	
2	The hand controller does not communicate with the center board for more than 4s	Bad contact or fracture of inserting wire	1.Check or replace the plug-in cable; 2.Replace the hand controlle 3.Replace the center board.	

40	The position sensor is abnormal for up-down motor in the rolling mechanism	<ol style="list-style-type: none"> 1. position sensor is bad; 2. connection is abnormal 3. The motor is broken or blocked; 4. The driving circuit device is damaged. 	<ol style="list-style-type: none"> 1. Check the connection between the sensor and the rolling mechanism board; 2. Check the connection between the main PCBA and the rolling mechanism board 3. Replace the sensor; 4. Move the rolling mechanism to the initial height position; 5. Replace the rolling mechanism board. 	<ol style="list-style-type: none"> 1. Start detection when the function is turned on 2. Automatic shutdown in case of failure, and not allowed to start.
41	Position coding anomaly of the rolling mechanism walking motor. That is ,the code disk is in the incorrect position.	<ol style="list-style-type: none"> 1. The position sensor is broken; 2. rolling mechanism overshoot 	<ol style="list-style-type: none"> 1. Replacement of sensors; 2. Move the rolling mechanism to the initial height position; 3. Replacement of rolling mechanism board 	<ol style="list-style-type: none"> 1. real-time detection; 2. Shut down automatically in the event of failure time. And not allowed to boot.
42	Abnormal speed senso of the rolling mechanism walking motor. That is ,no change of speed code disk was detected in excess of 6S.	<ol style="list-style-type: none"> 1. The motor is broken or blocked 2. Drive circuit device damage 	<ol style="list-style-type: none"> 1. Check the connection between the motor and the rolling mechanism board; 2. Check or replace motor; 3. Replacement of rolling mechanism board. 	<ol style="list-style-type: none"> 1. Detection when function is turned on; 2. Shut down automatically in the event of failure time, and not allowed to boot.
44	The position sensor is abnormal of Core motor. That is, no change of position code disk is detected over 10S	<ol style="list-style-type: none"> 1. The position sensor is broken 2. The motor is broken or blocked 3. Drive circuit device damage 	<ol style="list-style-type: none"> 1. Check the connection between the sensor and the rolling mechanism board; 2. Replace the sensor; 3. Check or replace motor; 4. Replacement of movemetn board 	<ol style="list-style-type: none"> 1. Detection when function is turned on; 2. Shut down automatically in the event of failure time. And not allowed to boot.

46	The speed sensor is abnormal for kneading motor in the rolling mechanism .That is, more than 6S did not detect the speed code disk change.	1. The motor is broken or blocked; 2. Drive circuit device damage	1. Check the connection between the motor and the rolling mechanism PCBA; 2. Check or replace motor; 3. Replacement of rolling mechanism PCBA	1.Detection when function is turned on; 2.Shut down automatically in the event of failure time. And not allowed to boot.
54	Kneading motor in the rolling mechanism position wide, medium and narrow are abnormal.	1.Position sensor is broken; 2.The motor is broken or blocked; 3.The driving circuit device is damaged	1.Check the connection between the sensor and the rolling mechanism PCBA; 2.Replace the sensor; 3.Check or replace the motor; 4.Replace the rolling mechanism PCBA; 5.Replace the brushless motor drive board.	1.Detection when function is turned on; 2.Shut down automatically in the event of failure time. And not allowed to boot.
55	Motor drive chip A4459 on the Main is broken.	1.The motor is blocked; 2.The driving circuit device is damaged	1.Replace the Main PCBA	1.Detection when function is turned on; 2.Shut down automatically in the event of failure time. And not allowed to boot.

3. Electrical Schematic Diagram



Title		
Size	Number	Revision
A4		
Date:	2020/02/21	Sheet of
File:	EVEI-8701/EI-8701/MCU_SchDoc	Drawn By:


5 . Tools List



Diagonal Pliers



Electric Screw Driver



Electric Screw Driver



Nipper Pliers



Cable Tie



Cross Head



Slot Type Screwdriver

Cross Screwdriver



Hexagonal Screwdriver



6 . Replacement of Accessories

① · Replacement of Backrest Pad

1. Use a small cable tie to pass through the zipper and pull open (figure 1) A total of seven (figure 1-2)
2. Take off the backrest pad (figure 3) then put on a new cloak and pull 7 zippers.

figure 1



figure 2



figure 3



② · Replacement of Back Cover

1. Take down 3 cloth pins (figure 1)
2. Take down 6 screws (figure 2)



figure 1



figure 3



figure 2

③ · Replacement of Side Plate

1. Unzip zippers of the side plate (figure 1)
2. Take down 4 screws (figure 2)
3. Remove the side plate, disconnect the gas hose (figure 3)




figure 1



figure 2



figure 3

④ · Replacement of Shoulder

Take down 4 screws and disconnect the gas hose (figure 1) take down the Shoulder (figure 2)




figure 1




figure 2

⑤ · Replacement of Leg Rest-1

1. Unzip the zippers (figure 1)
2. Remove 2 DK iron, move out the leg rest (figure 2-3)
3. Disconnect the 2 terminal and 1 air hose (figure 4)



figure 1




figure 2



figure 3



figure 4

⑤ · Replacement of Leg Rest-2

1.Connect the 2 terminal and 1 air hose (figure 1-2)

2.Hang up the leg rest, clip into the DK iron (figure 3-4)

3.Attention: the DK iron should snap into place, terminal white dot to white dot.



figure 1



figure 2



figure 3



figure 4



⑥ · Replacement of Air Pump

1. Take down 5 cloth pins (figure 1)
2. Take down 3 screws (figure 2)
3. Take down 4 screws of air pump, and cut off the cable tie on the air pump and the air hose, unplug the air hose from the air pump (figure 3)
4. Unplug the terminal on the Main PCBA (figure 4)
5. Unplug the 4 rubber feet on the iron frame (figure 5)



figure 1



figure 2




figure 3



figure 4



figure 5

⑦ · Replacement of Switching Power Supply

1. After opening the upper cover, remove 4 screws (figure 1)
2. Unplug the 2 terminals (figure 1)
3. Take down the Switching Power Supply(figure 2)



figure 1



figure 2

⑧ · Replacement of the Main PCB box of Quadruple Air Valve

1. After opening the upper cover, remove 3 screws (figure 1)
2. Pick up the air valve and pick up the metal buckles of the 6 air hose (figure 2)
3. Cut off the cable tie, pull out the 8 pins for terminal, then you can remove the quadruple air valve (figure 3-5)




figure 1




figure 2



figure 3



figure 4



figure 5

⑨ · Replacement of the main PCB box of Duplex Air Valve

1. After opening the upper cover, remove 3 screws (figure 1)
2. Pick up the air valve and pick up the metal buckles of the 3 air hose (figure 2)
3. Cut off the cable tie, pull out the 4 pins for terminal, then you can remove the duplex air valve (figure 3-5)




figure 1




figure 2



figure 3



figure 4




figure 5

⑩ · Replacement of Remote Control

1. Take down the side plate, you can see the connector of remote control (figure 1)
2. Unscrew the connector, unplug the connector, you can take out the remote control (figure 2)



figure 1



figure 1

⑪ • Replacement of Main PCBA and Fuse

1. Remove the fuse holder from the power input socket (figure 1), then remove the fuse (figure 2)
2. Unplug all terminals on the Main PCBA (figure 3), take down 4 screws (figure 4)



figure 1



figure 2



figure 3



figure 4

⑫ · Replacement of the Rolling Mechanism-1

1. Remove the backrest pad and flannel fabric (figure 1)
2. Remove the left and right baffle on the guideway (figure 2)
3. Remove the back cover, push the rolling mechanism down firmly, push the rolling mechanism to the left and right baffle on the guideway position (figure 3)



figure 1




figure 2




figure 3

⑫ · Replacement of the Rolling Mechanism-2

1. Front gear first out, then rear gear out (figure 1-2), you can take out the rolling mechanism from the guideway (figure 3)




figure 1



figure 2







figure 3

⑫ · Replacement of the Rolling Mechanism-3

Use a screwdriver to remove the 2 screws of the sixteen-core cable, use diagonal pliers to cut off the buckle of the sixteen-core cable, unplug the two terminals on the movement board, and unplug the air pipe on the rolling mechanism, then you can take out rolling mechanism.



⑫ · Replacement of the Rolling Mechanism-4

1.The rolling mechanism side is stuffed in (figure 1)

2.The rear gear is put into the guide rail from the position where the baffle is removed, and then the front gear is put into the guide rail (figure 2)

3.After putting it in, the movement should be pushed down, and the rear gear should be under the position of the guide rail removal baffle to lock the baffle (figure 3)



figure 1



figure 2



figure 3