














EC-385P (2) (Os-Pro Pinnacle)massage chair auto-check list







开启/关闭 : **KNEAD键 + TAP键 + POWER键** 同时住保持**2秒**后开启/关闭自动故障检测模式  
ON/OFF: **KNEAD + TAP + POWER**(buttons on the controler), press and hold the three buttons in two senconds to turn on the automatic analysis system model.





状态指示 : 进入自动故障检测模式后背光源闪烁, 有故障时手控器上的时间位置显示相应的故障代号, 同时蜂鸣器报警  
After activating the "auto-checking model", the display screen of the controller keeps flashing; if there is something wrong with the chair, the time area will show you the exact code of the malfunction, meanwhile the buffer will make noise.

| No. | Code  | Phenomenon   | Malfunction description  | Solutions   | Remarks           |
|-----|---|--|--|---|-------------------|
| 01  |  | remote control tested any key pressed more than 25 seconds | 1.one of the KEY has been blocked.   | 1.check the key of the remote control                                   | turn on the chair |
| 02  |  | remote control did not connected                           | 1.the remote control wire is broken or the remote control wire is disconnected | 1.reconnecte the remote control wire or change the remote control wire. | turn on the chair |

|    |   |  |   |   |                               |
|----|---|--|---|---|-------------------------------|
| 03 |    | backrest signal is abnormality                       | <ol style="list-style-type: none"> <li>1.backrest wire(black) is not well connected.</li> <li>2.up &amp; down limit sensor is broken</li> </ol>   | <ol style="list-style-type: none"> <li>1.check whether the backrest wire(black) is well connected</li> <li>2.change the up &amp; down limit sensor</li> </ol>           | turn on the chair             |
| 04 |    | backrest signal is abnormality                       | <ol style="list-style-type: none"> <li>1.backrest wire(black) is not well connected.</li> <li>2.the counting sensor of the rolling motor is broken</li> </ol>   | <ol style="list-style-type: none"> <li>1.check whether the backrest wire(black) is well connected</li> <li>2.change the counting sensor of the rolling motor</li> </ol> | activate the Rolling function |
| 07 |    | tested more than 2 width inspection signal           | <ol style="list-style-type: none"> <li>1.width inspection board is broken</li> <li>2.width inspection wire is not well connected</li> </ol>   | <ol style="list-style-type: none"> <li>1.change width inspection board</li> <li>2.change backrest wires. (black)</li> </ol>   | activate the Rolling function |
| 08 |   | more than 5 seconds did not tested the wide signal   | <ol style="list-style-type: none"> <li>1.width inspection board is broken</li> <li>2.the wire connect to the width inspection board is disconnected</li> <li>3.kneading motor is broken or kneading belt is lost</li> </ol> | <ol style="list-style-type: none"> <li>1.change width inspection board</li> <li>2.change backrest wires. (black and gray)</li> <li>3.change kneading motor</li> </ol>   | activate auto-check model     |
| 09 |  | more than 5 seconds did not tested the middle signal | <ol style="list-style-type: none"> <li>1.width inspection board is broken</li> <li>2.the wire connect to the width inspection board is disconnected</li> <li>3.kneading motor is broken or kneading belt is lost</li> </ol> | <ol style="list-style-type: none"> <li>1.change width inspection board</li> <li>2.change backrest wires. (black and gray)</li> <li>3.change kneading motor</li> </ol>   | activate auto-check model     |
| 10 |  | more than 5 seconds did not tested the narrow signal | <ol style="list-style-type: none"> <li>1.width inspection board is broken</li> <li>2.the wire connect to the width inspection board is disconnected</li> <li>3.kneading motor is broken or kneading belt is lost</li> </ol> | <ol style="list-style-type: none"> <li>1.change width inspection board</li> <li>2.change backrest wires. (black and gray)</li> <li>3.change kneading motor</li> </ol>   | activate auto-check model     |

|    |   |  |   |   |                           |
|----|---|--|---|---|---------------------------|
| 11 |    | more than 10 seconds didn't tested kneading signal   | 1.Main PCB is broken  | 1.change PCB  | activate auto-check model |
| 12 |    | when not kneading but the width inspection signal still can be tested                            | 1.Main PCB is broken  | 1.Change PCB  | activate auto-check model |
| 13 |    | tested signals from up & down limit sensor at the same time.                                     | 1.up & down limit sensor are broken<br>2.backrest wire(black) is disconnected.  | 1.Change up & down limit sensor<br>2.check whether the backrest wire(black)is well connected  | activate auto-check model |
| 14 |   | more than 40s didn't tested the signal from the up limit sensor                                  | 1.upper limit sensor is broken.<br>2.backrest wires( black and gray) are disconnected<br>3.rolling motor is broken or rolling motor wire disconnected | 1.change upper limit sensor<br>2.check whether the backrest wire(black) is well connected.<br>3.change rolling motor or rolling motor wire. | activate auto-check model |
| 15 |  | height counting signal error   | 1.the counting sensor of the rolling motor is broken<br>2.backrest wire(black) is disconnected  | 1.change the counting sensor of the rolling motor.<br>2.check whether the backrest wire(black) is well connected.                           | activate auto-check model |
| 16 |  | after tested signal from up limit sensor then tested signal from down limit sensor in 2 seconds. | 1.down limit sensor is broken   | 1.change down limit sensor<br>2.check whether the backrest wire(black) is well connected.<br>3.change rolling motor                         | activate auto-check model |

|    |   |  |   |  |                           |
|----|---|--|---|--|---------------------------|
| 17 |    | more than 40s didn't tested the signal from the up limit sensor                                  | <ol style="list-style-type: none"> <li>1.down limit sensor is broken</li> <li>2.the backrest wire(black) is disconnected.</li> <li>3.rolling motor is broken or disconnected</li> </ol>                             | <ol style="list-style-type: none"> <li>1.change down limit sensor</li> <li>2.check whether the backrest wire(black) is well connected.</li> <li>3.change rolling motor</li> </ol>  | activate auto-check model |
| 18 |    | after tested signal from down limit sensor then tested signal from up limit sensor in 2 seconds. | 1.upper limit sensor is broken.   | 1.change upper limit sensor  | activate auto-check model |
| 19 |    | can't test signal from foot rest recline actuator  | <ol style="list-style-type: none"> <li>1.foot rest recline actuator is broken</li> <li>2.foot rest actuator motor wire is disconnected</li> <li>3.the signal wire of foot rest actuator is disconnected.</li> </ol> | <ol style="list-style-type: none"> <li>1.change foot rest recline actuator</li> <li>2.check whether the foot rest recline actuator motor wire is well connected.</li> <li>3.check whether the signal wire of foot rest actuator is well connected</li> </ol> | activate auto-check model |
| 20 |  | test signals from front sensor and rear sensor at the same time.                                 | <ol style="list-style-type: none"> <li>1.the 6 core signal wire is disconnected.</li> <li>2.up &amp; down limit sensor of the foot rest are broken</li> </ol>   | <ol style="list-style-type: none"> <li>1.check whether the 6 core signal wire is well connected.</li> <li>2.change up &amp; down limit sensor of the foot rest.</li> </ol>   | activate auto-check model |
| 21 |  | didn't test signal from front sensor of the footrest more than 20 seconds.                       | <ol style="list-style-type: none"> <li>1.the down limit sensor of the foot rest is broken</li> <li>2.foot rest extending motor is broken or disconnected</li> </ol>   | <ol style="list-style-type: none"> <li>1.change down limit sensor of the footrest</li> <li>2.change the footrest extending motor or check whether the motor wire is well connected.</li> </ol>   | activate auto-check model |
| 22 |  | After tested front sensor signal, then tested front sensor signal in 2.5 seconds.                | 1.the upper limit sensor of foot rest is broken   | 1.change the upper limit sensor of the footrest.   | activate auto-check model |

|    |   |   |  |  |                                  |
|----|---|---|--|--|----------------------------------|
| 23 |    | <p>didn't tested rear sensor signal in 20 seconds</p>   | <p>1.the upper limit sensor of foot rest is broken<br/>2.foot rest extending motor is broken or the motor wire is disconnected.</p>                                  | <p>1.change upper limit sensor of the foot rest.<br/>2.change foot rest exteding motor</p>   | <p>activate auto-check model</p> |
| 24 |    | <p>After tested rear sensor signal, hen tested front sensor signal in .5 seconds.</p>                 | <p>1.the lower limit sensor of the foot rest is broken</p>   | <p>1.change footrest lower limit sensor</p>  | <p>activate auto-check model</p> |
| 25 |   | <p>when start the backrest recline ctuator, there is no counting signal for more than 2.5 seconds</p> | <p>1.backrest recline actuator is broken<br/>2.backrest recline actuator wire is disconnected<br/>3.the signal wire of the backrest recline wire is disconnected</p> | <p>1.change backrest recline actuator<br/>2.check whether the backrest recline actuator motor wire is well connected.<br/>3.check whether the signal wire of the backrest recline actuator is well connected</p> | <p>activate auto-check model</p> |
| 26 |  | <p>when start the zero-gravity ictuator, there is no counting signal for more than 2.5 seconds</p>    | <p>1.Zero-gravity actuator is broken<br/>2.zero-gravity actuator wire is disconnected.<br/>3.the signal wire of zero-gravity actuator is disconnected</p>            | <p>1.change zero-gravity actuator<br/>2.check whether the zero-gravity motor wire is well connected.<br/>3.check whether the signal wire of zero-gravity actuator is well connected</p>                          | <p>activate auto-check model</p> |



