

1. Unzip the zipper between cushion and legrest



2. You can see the zipper of backpad. Unzip it and then you can take the backpad off. When you unzip the backpad, you can see there is connection to heating pad and airbag inside the backpad.

